



**Defender<sup>®</sup> 6000 Indicators  
Instruction Manual**

**Defender<sup>®</sup> 6000 Waagen  
Bedienungsanleitung**

**Indicadores Defender<sup>®</sup> 6000  
Manual de instrucciones**

**Manuel d'instructions sur les  
indicateurs de Defender<sup>®</sup> 6000**

**Indicatori<sup>®</sup> Defender 6000  
Manuale di istruzioni**



# Table of Contents

<b>1.</b>	<b>INTRODUCTION .....</b>	<b>3</b>
1.1.	SAFETY PRECAUTIONS .....	3
1.2.	INTENDED USE .....	3
1.3.	OVERVIEW OF PARTS AND CONTROLS .....	4
1.4.	MAINBOARD .....	5
1.5.	CONTROL FUNCTIONS .....	6
<b>2.</b>	<b>INSTALLATION .....</b>	<b>9</b>
2.1	UNPACKING .....	9
2.2	EXTERNAL CONNECTIONS.....	9
2.2.1	Scale Base with EasyConnect™ Connector.....	9
2.2.2	Power input to i-DT61PW.....	9
2.2.3	AC Power to i-DT61XWE.....	9
2.3	INTERNAL CONNECTIONS .....	9
2.3.1	Opening the Housing.....	9
2.3.2	Scale Base without EasyConnect™ Connector.....	11
2.3.3	Communication Interface Cable to i-DT61PW.....	14
2.3.4	RS232 Interface Cable to i-DT61XWE.....	15
2.4	MOUNTING BRACKET.....	15
<b>3.</b>	<b>OPERATION .....</b>	<b>16</b>
3.1	TURNING THE SCALE ON/OFF.....	16
3.2	WEIGHING MODE .....	16
3.2.1	Enter the Mode and Start Weighing .....	16
3.2.2	Accumulation and Statistics .....	16
3.2.3	Check .....	17
3.2.4	Application Settings .....	18
3.3	COUNTING MODE .....	19
3.3.1	Enter the Mode .....	19
3.3.2	Establish an APW .....	19
3.3.3	Start Counting .....	19
3.3.4	Application Settings .....	19
3.4	PERCENT MODE .....	20
3.4.1	Enter the Mode .....	20
3.4.2	Establish a Reference Weight.....	20
3.4.3	Start Percent Weighing .....	20
3.4.4	Application Settings .....	20
3.5	DYNAMIC MODE.....	21
3.5.1	Enter the Mode .....	21
3.5.2	Start Dynamic Weighing .....	21
3.5.3	Application Settings .....	21
3.6	FILLING MODE.....	22
3.6.1	Enter the Mode .....	22
3.6.2	Start Filling .....	22
3.6.3	Resume and Pause Filling.....	22
3.6.4	Display of the Dot Matrix Screen.....	22
3.6.5	Application Settings .....	23
<b>4.</b>	<b>MENU SETTINGS .....</b>	<b>24</b>
4.1	MENU NAVIGATION .....	24
4.1.1	User Menu.....	24
4.1.2	Button Navigation.....	25
4.2	CALIBRATION MENU.....	26
4.2.1	Initial Calibration.....	26
4.2.2	Zero Calibration [ZERR].....	26
4.2.3	Span Calibration [SPAN].....	26
4.2.4	Linearity Calibration [L #? ].....	27
4.2.5	GEO Adjustment [GEO].....	27
4.2.6	Calibration Test [L.E.S.E] .....	28

4.2.7	<i>End Cal [End]</i> .....	28
4.3	SETUP MENU .....	29
4.4	READOUT MENU .....	33
4.5	UNIT MENU.....	35
4.6	GLP/GMP MENU .....	35
4.7	COMMUNICATION .....	36
4.7.1	<i>RS232 Menu</i> .....	36
4.7.2	<i>Print Menu</i> .....	37
4.7.3	<i>RS485 Configuration</i> .....	40
4.7.4	<i>Ethernet Configuration</i> .....	40
4.7.5	<i>Analog Configuration</i> .....	40
4.8	MEMORY .....	40
4.8.1	<i>Memory menu (for i-DT61PW model)</i> .....	40
4.8.2	<i>USB memory (for i-DT61XWE model)</i> .....	40
4.8.3	<i>Alibi Memory (for i-DT61XWE model)</i> .....	41
4.9	DISCRETE I/O (FOR I-DT61XWE MODEL) .....	46
4.9.1	<i>I/O Type</i> .....	46
4.9.2	<i>Input</i> .....	47
4.9.3	<i>Output</i> .....	47
4.10	LOCK KEY CONFIGURATION .....	47
4.11	LIBRARY (FOR I-DT61XWE MODEL).....	48
4.12	USER (FOR I-DT61XWE MODEL).....	50
4.13	USB (FOR I-DT61XWE MODEL) .....	52
4.13.1	<i>USB Flash Drive</i> .....	52
4.13.2	<i>RFID</i> .....	52
4.13.3	<i>Barcode</i> .....	52
4.13.4	<i>Keyboard</i> .....	52
4.13.5	<i>Wi-Fi/Bluetooth Dongle (Optional)</i> .....	53
<b>5.</b>	<b>LEGAL FOR TRADE</b> .....	<b>55</b>
5.1	SETTINGS.....	55
5.2	VERIFICATION .....	55
5.3	SEALING .....	55
<b>6.</b>	<b>MAINTENANCE</b> .....	<b>57</b>
6.1	CLEANING.....	57
6.1.1	<i>Cleaning for i-DT61PW Model</i> .....	57
6.1.2	<i>Cleaning for i-DT61XWE Model</i> .....	57
6.2	TROUBLESHOOTING .....	58
6.3	SERVICE INFORMATION .....	58
<b>7.</b>	<b>TECHNICAL DATA</b> .....	<b>59</b>
7.1	SPECIFICATIONS .....	59
7.2	TABLE OF GEO VALUES.....	61
<b>8.</b>	<b>COMPLIANCE</b> .....	<b>62</b>
<b>9.</b>	<b>APPENDICES</b> .....	<b>64</b>
9.1	APPENDIX A.....	64
9.2	APPENDIX B.....	66

# 1. INTRODUCTION

This manual contains installation, operation and maintenance instructions for i-DT61PW and i-DT61XWE indicators. Please read it completely before installation and operation.

## 1.1. Safety Precautions

### Definition of Signal Warnings and Symbols

Safety notes are marked with signal words and warning symbols. These show safety issues and warnings. Ignoring the safety notes may lead to personal injury, damage to the instrument, malfunctions and false results.

WARNING	For a hazardous situation with medium risk, possibly resulting in severe injuries or death if not avoided.
CAUTION	For a hazardous situation with low risk, resulting in damage to the device or the property or in loss of data, or minor or medium injuries if not avoided.
ATTENTION	For important information about the product. May lead to equipment damage if not avoided.
NOTE	For useful information about the product.

### Warning Symbols



General hazard



Explosion hazard



Electrical shock hazard

### Safety Precautions



**CAUTION:** Read all safety warnings before installing, making connections, or servicing this equipment. Failure to comply with these warnings could result in personal injury and/or property damage. Retain all instructions for future reference.

- Before connecting power, verify that the AC adapter's input voltage range and plug type are compatible with the local AC mains power supply.
- Do not position the equipment such that it is difficult to reach the power connection.
- Only connect the power cord to a compatible grounded electrical outlet.
- Make sure that the power cord does not pose a potential obstacle or tripping hazard.
- Operate the equipment only under ambient conditions specified in these instructions.
- The equipment is for indoor use only.
- Do not operate the equipment in hazardous or unstable environments.
- Do not place the equipment upside down on the platform.
- Use only approved accessories and peripherals.
- Disconnect the equipment from the power supply when cleaning.
- Service should only be performed by authorized personnel.



**WARNING:** Never work in an environment subject to explosion hazards! The housing of the instrument is not gas tight. (Explosion hazard due to spark formation, corrosion caused by the ingress of gases).



**WARNING:** Electrical shock hazards exist within the housing. The housing should only be opened by authorized and qualified personnel. Remove all power connections to the unit before opening.

## 1.2. Intended Use

This instrument is intended for use in light industry. It must only be used for measuring the parameters described in these operating instructions. Any other type of use and operation beyond the limits of technical specifications, without written consent from OHAUS, is considered as not intended. This instrument complies with current industry standards and the recognized safety regulations; however, it can constitute a hazard in use. If the instrument is not used according to these operating instructions, the intended protection provided by the instrument may be impaired.