



VX 11.1 - Test tube insert

Attachment for Eppendorf tubes or test tubes
Bore holes (number): 70
Hole Ø: 10 mm