

Corning® Lambda™ EliteMax Semi-automated Benchtop Pipettor

Frequently Asked Questions

The logo consists of the word "CORNING" in a white, uppercase, sans-serif font, centered within a solid orange square.

General

1. How do I operate this instrument?

For operating instructions, refer to the Corning Lambda EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

2. What items come with this instrument?

Each instrument is delivered with a touch screen controller, external power supply, portrait adapter plate, instruction manual, and calibration certificate. Note that due to the length of the instruction manual, it will come on a thumb drive in an effort reduce printing and increase sustainability.

3. What plug types come with the external power supply?

Each instrument is delivered with the following plug types: United States (US), United Kingdom (UK), Europe (EU), and China (CN) plug types.

Software

1. How do I access the software for the instrument?

The touch screen controller has the software preloaded on the device and no download is required.

2. What happens if there is a software update?

To be notified of any software updates, follow the registration instructions on the instruction manual thumb drive. For software update instructions, refer to the Corning Lambda EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

3. What do I do if the system crashes?

The instrument has collision detection features and will notify the user about a possible crash. For more details about the crash recovery routine, refer to the Corning Lambda EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

Pipet Tips

1. What kinds of pipet tips are compatible with this instrument?

This instrument is designed to be used with Corning EliteMax tips only and should not be operated with any other types of tips.

2. What are the Corning EliteMax tip types and tip size ranges?

The Corning EliteMax tips are polypropylene, 96-well ANSI/SLAS formatted racked tips with volumes of 20, 30, 50, 165, and 250 μ L. Sterile and non-sterile versions are available for all tip sizes, and wide bore tips are available in both 165 and 250 μ L sizes.

3. What types of reagents are compatible with the Corning EliteMax tips?

For a list of reagents compatible with polypropylene tips, refer to the Chemical Resistance Chart (CLS-DL-CC-082) at www.corning.com/lifesciences.

Other

1. Can this instrument fit under a hood?

Yes. The instrument is designed to fit under any standard sized hood. The dimensions of the instrument and touch screen controller can be found in the Corning® Lambda™ EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

2. What plates are compatible with this instrument?

All standard ANSI/SLAS formatted plates are compatible with this instrument.

3. How do I switch from portrait to landscape position on the deck plate?

Use the adapter plate to transition between portrait and landscape positions. For more information, refer to the Corning Lambda EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

4. Can this instrument be used with UV light?

Yes. The instrument can be used with UV light. Note that long exposure to UV light might fade the colors but won't affect the operation or performance of the instrument.

5. What is ANSI/SLAS format?

This standard defines the well center positional requirements of a microplate as specified in American National Standards covering these microplates (as referenced at www.slas.org).

6. What are the performance specifications and technical data?

For performance specifications and technical data, refer to the Corning Lambda EliteMax Semi-automated Benchtop Pipettor Instruction Manual (CLS-AN-671DOC) at www.corning.com/lifesciences.

Warranty/Disclaimer: Unless otherwise specified, all products are for research use or general laboratory use only.* Not intended for use in diagnostic or therapeutic procedures. Not for use in humans. These products are not intended to mitigate the presence of microorganisms on surfaces or in the environment, where such organisms can be deleterious to humans or the environment. Corning Life Sciences makes no claims regarding the performance of these products for clinical or diagnostic applications. *For a listing of US medical devices, regulatory classifications or specific information on claims, visit www.corning.com/resources.

CORNING

Corning Incorporated
Life Sciences

www.corning.com/lifesciences

NORTH AMERICA

t 800.492.1110
t 978.442.2200

ASIA/PACIFIC

Australia/New Zealand
t 61 427286832

Chinese Mainland
t 86 21 3338 4338

India

t 91 124 4604000

Japan

t 81 3-3586 1996

Korea

t 82 2-796-9500

Singapore

t 65 6572-9740

Taiwan

t 886 2-2716-0338

EUROPE

CSEurope@corning.com

France

t 0800 916 882

Germany

t 0800 101 1153

The Netherlands

t 020 655 79 28

United Kingdom

t 0800 376 8660

All Other European Countries

t +31 (0) 206 59 60 51

LATIN AMERICA

grupoLA@corning.com

Brazil

t 55 (11) 3089-7400

Mexico

t (52-81) 8158-8400