

FR- Notice d'emploi – Réf 2141NT – Double thermo Int/ext

Caractéristiques :

- Température intérieure : 0 à +60°C
- Température extérieure : -40°C à + 60°C
- Précision : $\pm 1^\circ\text{C}$
- Résolution : 0,1°C
- Piles : 2xAAA

Fonctionnement :

- Enlever la trappe de pile à l'arrière de l'appareil et insérer 2 piles AA en veillant à respecter la polarité.
- La température mesurée par le capteur interne et la sonde filaire s'affiche à l'écran.
- En fonction du lieu de stockage du thermomètre, attendre quelques minutes afin que les températures se stabilisent.

Note : veillez à déposer les piles et matériel usagés dans un endroit écologiquement approprié.

EN- User manual – Réf 2141NT – Indoor/Outdoor digital thermometer

Specifications :

- Indoor temperature: 0 to +60°C
- Outdoor temperature: -40°C to + 60°C
- Accuracy : $\pm 1^\circ\text{C}$
- Resolution : 0,1°C
- Battery : 2xAAA

Operation :

- Remove the battery cover at the back of the thermometer and insert 2x AA batteries, ensuring that the polarity is respected.
- The temperature measured by the internal sensor and the wired sensor is displayed on the screen.
- Depending on where the thermometer is stored, wait a few minutes for temperatures to stabilize.

Note: Be sure to place used batteries and equipment in an environmentally appropriate location.