



## H 38 Holding rod

For fastening a temperature sensor or ETS-D5/6 with a boss head H 44 to the support rod H 16 V.