



AS 501.5 Dish attachment

For smoothly shaking dishes, but also for smooth mixing in vessels with a large, flat bottom (widenecked Erlenmeyer flasks and beakers). A plastic foil with mild adhesive prevents the vessel from slipping.

Dimensions (W x D x H): 450 x 450 x 45 mm

Set-up plate: 420 x 420 mm

Weight: 1.120 g