



MANUAL

PART NUMBER

257092

# **Timer with 2 channels ClearLine**

## Operation of time function

- Press and hold CLOCK key, display time will flash,
- Press HR/MIN/SEC key to set hour, minute, second separately.
- After settings, press CLOCK key to confirm and return to normal state

#### **Alarm operation**

- Press and hold ALARM key, alarm time will flash
- Press HR /MIN /SEC key to set hour, minute, second separately.
- After settings, press ALARM key to confirm and return to normal state.
- Under any state, press ALARM ON/OFF key to switch on / off alarm function,

#### **Alarm SNOOZE**

- Alarm rings during 1 mn, if no key has been pressed and start again after 5 mn pause : meanwhile screen displays ZZ sign.
- Press ALARM ON/OFF key, to stop definitely alarm function

### **Counting UP**

- Press START/STOP to start stopwatch function
- Press again to stop stopwatch

#### **Counting down**

- Press TIMER1 or TIMER2 key, to show TIMER1 or TIMER2 sign and 0:00 00.
- Press HR/MIN/SEC to set count down time to maximum 23:59 59.
- Press START/STOP key to start / stop count down timer
- When time elapsed, alarm rings during 1 mn and start counting up. Time's up will count until 23:59 99, and back again from 0:00 00
- Press START/STOP key to stop time's up
- Press CLEAR to reset timer (note: memory will be cancelled, too)
- Anytime, press CLOCK ALARM to recall Time and Alarm modes.

### **Memory function**

- Under function of TIMER1 or TIMER2, press MEMORY key to display memory time set.
- Press CLEAR to cancel memory

Note: Be careful to put end of life equipment and batteries in an environmentally suitable place.

### Units:

1 timer

RoHS





