

# SUPERBLAST AUTOCLAVE

## SPECIALLY FOR CLEAN ROOMS

Alternative to COVACLAVE goggle, SUPERBLAST AUTOCLAVE offers a panoramic vision and an unequalled comfort, with PLATINUM® coating included.



SUPBLCLAVE

92 g

- + VENTILATED FRAME AND HIGH-COMFORT
- + AUTOCLAVABLE GOGGLES
- + OVERFLOW CHUTE FOR LIQUIDS
- + ADJUSTABLE STRAP AND CLEAN
- + FITS OVER PRESCRIPTION GLASSES
- + POLYCARBONATE LENS
- + PLATINUM COATING ( +P )
- + COMPATIBLE WITH HALF-MASK RESPIRATOR

**bolle**  
SAFETY

# SUPERBLAST AUTOCLAVE

## SPECIALLY FOR CLEAN ROOMS

MODEL	VERSIONS	REFERENCES	LENS MARKING	FRAME MARKING	COATINGS
<b>SUPERBLAST AUTOCLAVE</b>	Ventilated Autoclave	SUPBLCLAVE	2C-1.2 ☞ 1 BT KN CE	☞ EN166 3 4 BT CE	Anti-scratch/Anti-fog (*☞)

### LENS MARKING

#### Optical class symbols:

1. Continuous work

#### Mechanical strength symbols:

B. Medium energy impact, resists a 6 mm, 0.86 g ball at 120 m/s.

T. The letter T, immediately after the mechanical strength symbol, authorises use for high speed particles at extreme temperatures.

#### Others symbols:

K. Resistance to surface damage by fine particles

N. Resistance to fogging (optional)

CE European standard ☞ Manufacturer name

### FRAME MARKING

**EN 166:** guaranteed minimum resistance of the protective eyewear against everyday risks including dropping the protective eyewear onto the ground, ageing by light exposure, exposure to heat or corrosion etc.

3. Liquid droplets or splashes.

4. Large dust particles > 5 microns.

B. Medium energy impact, resists a 6 mm, 0.86 g ball at 120 m/s.

T. The letter T, immediately after the mechanical strength symbol, authorises use for high speed particles at extreme temperatures.

CE European standard ☞ Manufacturer name

**Bollé Safety product approval certificates to CE standards will be sent on request.**

### CLEANING AND STORAGE

**CLEANING:** The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

**MAINTENANCE:** Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

**STORAGE:** All products must be stored in a dry and clean environment.

PACKAGING AND EAN 13 CODE	
	SUPBLCLAVE
Individual plastic bag	3660740008239
5 safety goggles per box	3660740108236
65 safety goggles per outer pack	3660740208233

CHARACTERISTICS	
LENSES	PC - 2,2 mm - Curve 5
FRAME	Special Auto-Clave TPR
TEMPLES	Non applicable
STRAP	Adjustable / Isoprene
FOAM	No
MAINTENANCE AND CLEANING	Soapy water



14/02/2017

Europe Bollé Safety  
95 rue Louis Guérin  
69100 Villeurbanne - France  
Tél. : 00 33 (0) 4 78 85 23 64  
Fax : 00 33 (0) 4 78 85 28 56  
contact@bolle-safety.com

**bolle-safety.com**

U.K. Bollé Safety  
Unit C83 - Barwell Business Park Leatherhead Road - Chessington  
Surrey - KT9 2NY  
Tél. : 00 44 (0)208 391 4700  
Fax : 00 44 (0)208 391 4733  
e-mail : sales@bolle-safety.co.uk

**bolle**  
SAFETY