



Instructions for using the Checkit® Go

1. Fill it




Draw dye into the pipette or robot's tips.

2. Dispense it




Pipette the dye into the wells.

IMPORTANT: It is crucial that the dye is dispensed into the center of each well. Avoid splatter or dispensing air bubbles.




3. Flip it



Using light force, flip up the 8-well tab with your finger or pipette tips to fully vertical.

4. Check it




In a few seconds, use the graduations to determine the dispensed volume.

RS18-0101B



For more information, visit:
Checkit.nextadvance.com



Please Note:

The Checkit® Go has eight precision glass capillaries for evaluating the volume dispensed by your pipette or robot.

Caution: Always wear personal protective equipment (PPE), including goggles.

Operation: Place the Checkit on a level surface. Empty the dye from one of the tubes into the built-in trough or use the dye straight from the tube. The tab with eight wells should be in the extended horizontal position. Set your multi-channel pipette or robot to the corresponding volume and follow the steps illustrated on the other side of this sheet. For example, on a 20 μ L Checkit Go, each channel is designed for measuring 20 μ L.

The Checkit Go is accurate to $\pm 2\%$.

