


Humidity Chamber HCP240

Active humidity control creates a controlled environment for accelerated life tests and 85/85 tests.



On this page, you can find all the essential technical data on the Memmert humidity chamber HCP. Our customer relations team will be pleased to help if you want further information. If you should require a customised special solution, please contact our technical specialists at myAtmoSAFE@memmert.com.



Working-temperature range +7 above ambient temperature up to +90 °C Setting accuracy temperature range +18 to +90 °C Temperature sensor 2 Pt100 sensors DIN Class A in 4-wire-circuit for mutual monitoring, taking over functions in case of an error Humidity	Temperature		
Setting accuracy temperature Temperature sensor 2 P1100 sensors DIN Class A in 4-wire-circuit for mutual monitoring, taking over functions in case of an error Humidity Humidity Control Setting ange active humidity control Setting accuracy humidity 0.5 % rh Control technology Control COCKPIT TwinDISPLAY, Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFF-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian dijustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime summertime/wintertime Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature.	Working-temperature range	+7 above ambient temperature up to +90 °C	
Temperature sensor 2 Pt100 sensors DIN Class A in 4-wire-circuit for mutual monitoring, taking over functions in case of an error Humidity Humidity Control Setting range active humidity control Setting accuracy humidity 0.5 % rh Control technology Control COCKPIT TwinDISPLAY: Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFF-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heating is switched off in case of over- or undertemperature, heatin	Setting temperature range	+18 to +90 °C	
Humidity Humidity Control Setting ange active humidity control Setting accuracy humidity	•	0.1 °C	
Setting range active humidity control Setting accuracy humidity Control technology Control technology ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature and humidity control	Temperature sensor		
Setting range active humidity control Setting accuracy humidity 0.5 % rh Control technology ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertimes/wintertime Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Humidity		
Setting accuracy humidity 0.5 % rh Control technology ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Humidity Control		
Control technology ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature integral fault diagnostics for temperature and humidity control		20 to 95 % rh and rh-Off	
ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Setting accuracy humidity	0.5 % rh	
ControlCOCKPIT TwinDISPLAY. Adaptive multifunctional digital PID-microprocessor controller with 2 high-definition TFT-colour displays. Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control			
Language setting German, English, Spanish, French, Polish, Czech, Hungarian adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature integral fault diagnostics for temperature and humidity control	Control technology		
adjustable parameters temperature (Celsius or Fahrenheit), relative humidity, programme time, time zones, summertime/wintertime Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start untill the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	ControlCOCKPIT		
Timer Digital backwards counter with target time setting, adjustable from 1 minute to 99 days Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature integrated over- and humidity control	Language setting	German, English, Spanish, French, Polish, Czech, Hungarian	
Function SetpointWAIT the process time does not start until the set temperature is reached Calibration three freely selectable values each, temperature and humidity Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature integral fault diagnostics for temperature and humidity control	adjustable parameters		
Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature integral fault diagnostics for temperature and humidity control	Timer	Digital backwards counter with target time setting, adjustable from 1 minute to 99 days	
Communication Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Function SetpointWAIT	the process time does not start until the set temperature is reached	
Interface Ethernet LAN, USB Documentation programme stored in case of power failure Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Calibration	three freely selectable values each, temperature and humidity	
Programming AtmoCONTROL software on a USB stick for programming, managing and transferring programmes via Ethernet interface or USB port Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control		Ethernet LAN, USB	
Safety AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Documentation		
AutoSAFETY additionally integrated over- and undertemperature monitor "ASF", automatically following the setpoint value at a preset tolerance range, alarm in case of over- or undertemperature, heating is switched off in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control	Programming	AtmoCONTROL software on a USB stick for programming, managing and transferring programmes	
in case of overtemperature Autodiagnostic system integral fault diagnostics for temperature and humidity control			
Alarm visual and acoustic	Autodiagnostic system	integral fault diagnostics for temperature and humidity control	
	Alarm	visual and acoustic	

Heating concept

6 sides	large-area multi-function heating system on four sides with additional door and back heating to avoid
	condensation

Standard equipment

Works calibration certificate	Works calibration certificate (measuring point chamber centre) at 60 °C with 75 % rh	
Entry port	Entry port (silicone), 40 mm clear diameter, for introducing connections, moisture tight, can be closed by silicone stopper, at the back, centre left	
Door	Additional heated inner glass door	
Door	fully insulated stainless steel door with 2-point locking (compression door lock)	
Internals	2 perforated stainless steel shelf/shelves	

Stainless steel interior

Dimensions	w _(A) x h _(B) x d _(C) : 600 x 810 x 500 mm (d less 35 mm for fan)	
Interior	WSt. 1.4301 (ASTM 304)	
Volume	241 I	
Max. number of internals	12	
Max. loading of chamber	140 kg	
Max. loading per internal	15 kg	

Textured stainless steel casing

Dimensions	w _(D) x h _(E) x d _(F) : 759 x 1180 x 691 mm (d +56mm door handle)	
------------	--	--

Electrical data

Voltage Electrical load	230 V, 50/60 Hz approx. 1840 W	
Voltage Electrical load	115 V, 50/60 Hz approx. 1840 W	

Ambient conditions


Ambient temperature	ient temperature 10 °C to 30 °C	
Set Up	The distance between the wall and the rear of the appliance must be at least 15 cm. The clearance from the ceiling must not be less than 20 cm and the side clearance from walls or nearby appliance must not be less than 5 cm.	
Humidity rh	max. 70 %, non-condensing	
Altitude of installation	max. 2,000 m above sea level	
Overvoltage category	II	
Pollution degree	2	

Packing/shipping data

Transport information	The appliances must be transported upright	
Customs tariff number	8419 8998	
Country of origin	Federal Republic of Germany	
WEEE-RegNo.	DE 66812464	
Dimensions approx incl. carton	w x h x d: 840 x 1360 x 900 mm	
Net weight	approx. 110 kg	
Gross weight carton	approx. 145 kg	

Temperature Humidity Working Range HCP

Not all climate chambers are the same. The humidity content of the chamber load, the ambient conditions and the respective temperature-humidity working range are decisive factors in the selection of the right appliance. In the adjacent diagram, you can see the possible temperature/humidity combinations for our humidity chambers HCP. Within the respective temperature-humidity range, permanent operation is possible (at an ambient temperature of 22 °C \pm 3 K, relative humidity < 50 %). Condensation may occur in the threshold range. To which extent depends on the humidity content of the chamber load and the ambient conditions.



Temperature-humidity working range HCP

Standard units are safety-approved and bear the test marks

